Technical data

The Walkstool is available in two model types Comfort and Basic. It comes with two seat heights ranging from 45cm/18in as in a normal chair, and to 75cm/30in to accommodate for hunters, tall people, people with problem with back and/or disc and not to forget Big People.

Walkstool Comfort

The Walkstool Comfort 45cm/18in, Walkstool Comfort 55cm/22in, Walkstool Comfort 65cm/26in and Walkstool Comfort 75cm/30in are for people who like to feel very comfortable when they sit down.

The seats are approximately 40%, 60% and 80% bigger than a normal seat for a three legged stool. The taller the stool, the bigger the seat size.

Walkstool Basic

The Walkstool Basic 50cm/20in and Walkstool Basic 60cm/24in are mainly aimed at the mass market. The seat is made of black polyester and is approximately 20% bigger in size than a normal seat for a three legged stool. The upper legs are grey to match the seat.



Walkstool Comfort 45 L 725 g / 26 oz Max 200 kg / 440 lbs



-37,5 cm /15 in-

Walkstool Comfort 55 XL 800 g / 28 oz Max 225 kg / 495 lbs



Walkstool Comfort 65 XXL 850 g / 30 oz Max 250 kg / 550 lbs



Walkstool Comfort 75 XXL 900 g / 32 oz Max 250 kg / 550 lbs




Walkstool Basic 50 M 650 g / 23 oz Max 150 kg / 330 lbs



Walkstool Basic 60 M 725 g / 26 oz Max 175 kg / 385lbs

Patented US Pat.no. 5,851,052/6,135,557 Australia no. 749.687 Brazil no. 9812952-0 Canada no. 2.306.180 China no. ZL98810406.7 Germany no. 69814128.8-08 France, Italy, Spain and UK no. 1024731. Japan no. 4237397



The four Swedish models are delivered in a practical pouch for storage and carriage.



To lock lower legs when not using Walkstool Comfort models, twist the legs so they are locked by the rubber feet being close together. To use Walkstool Comfort models, do the opposite and you unlock the lower legs.

Be careful when sitting on the Walkstool on uneven ground. Avoid to put all pressure on one or two lower legs. Improper use of the Walkstool can result in bodily injury or harm. Always check the Walkstool before using it to make sure that the red button is in the proper locked position. User assumes all responsibility for use and operation of the Walkstool.

Zamin tavana tajhiz co. www.ir-geo.com